

做最好用的运动控制 DO THE BEST TO USE MOTION CONTROL

EtherCAT Motion Control Card

XPCIE1032H





Vision

Motion Controller

Motion Controlle



Motion Control Card



IO Expansion Module



HMI



Zmotion[®]

The motion controller provides rich interface, and it has excellent motion control performance, which can meet the expansion requirements of various projects.

This manual is copyrighted by Shenzhen Technology Co., Ltd., without the written permission of the Zmotion Technology, no person shall reproduce, translate and copy any content in this manual. The above-mentioned actions will constitute an infringement of the copyright of the company's manual, and Zmotion will investigate legal responsibility according to law.

For details about the ZMC controller software and the introduction and routine of each command, please refer to the ZBASIC software manual.

Information contained in this manual is only for reference. Due to improvements in design and functions and other aspects, Zmotion Technology reserves the final interpretation! Subject to change without notice!

Pay attention to safety when debugging the machine!

Please be sure to design an effective safety protection device in the machine, and add an error handling program in the software, otherwise Zmotion has no obligation or responsibility for the loss caused.

In order to ensure the safe, normal and effective use of the product, please be sure to read this product manual carefully before installing and using the product.

🖶 Safety Statement

- This chapter describes the safety precautions required for the correct use of this product. Before using this product, please read the instructions for use and correctly understand the relevant information on safety precautions.
- This product should be used in an environment that meets the design specifications, otherwise it may cause equipment damage or personal injury, and malfunctions or component damage caused by failure to comply with relevant regulations are not within the scope of product quality assurance.
- Zmotion will not take any legal responsibility for personal safety accidents and property losses caused by failure to comply with the contents of this manual or illegal operation of products.

Safety Level Definition

According to the level, it can be divided into " Danger " and " Caution ". Failure to operate as required may result in moderate injury, minor injury or equipment damage.

Please keep this guide in a safe place for reading when needed, and be sure to hand this manual to the end user.

		Install
	٠	When the controller is disassembled, all external power supplies used by the
		system should be disconnected before operation, otherwise it may cause
		misoperation or damage to the equipment.
	٠	It is forbidden to use in the following places: places with dust, oil fume, conductive
Danger		dust, corrosive gas and flammable gas; places exposed to high temperature,
		condensation, wind and rain; places with vibration and shock. Electric shock, fire
		and misuse can cause product damage and deterioration.
_	٠	Avoid metal shavings and wire ends falling into the hardware circuit board during
		installation.
	٠	After installation, ensure that there are no foreign objects on the hardware circuit
Notice		board.
	•	When installing, make it tightly and firmly with the mounting frame.

	•	Improper installation of the controller may result in misoperation, failure and fire.		
		Wiring		
	٠	The specifications and installation methods of the external wiring of the		
		equipment shall comply with the requirements of local power distribution		
		regulations.		
	•	When wiring, all external power supplies used by the system should be		
<u>/!</u> \		disconnected before operation.		
Dangar	٠	When powering on and running after the wiring work is completed, the terminals		
Danger		attached to the product must be installed.		
	٠	Cable terminals should be well insulated to ensure that the insulation distance		
		between cables will not be reduced after the cables are installed on the terminal		
		block.		
	٠	Avoid metal shavings and wire ends falling into the hardware circuit board during		
		installation.		
	٠	The cable connection should be carried out correctly on the basis of confirming		
		the type of the connected interface.		
$\mathbf{\Lambda}$	٠	It should be confirmed that the cables pressed into the terminals are in good		
· · ·		contact.		
Notice	٠	Do not bundle the control wires and communication cables with the main circuit		
		or power supply wires, etc., and the distance between the wires should be more		
		than 100 mm, otherwise noise may cause malfunction.		
	•	If the controller is not installed properly, it may cause electric shock or equipment		
		failure or malfunction.		

Content

Chapter	I Product	tion Information	2
1.1.	Produ	ction Introduction	2
1.2.	Syste	m Framework	2
1.3.	Functi	ional Features	3
1.4.	Mode	& Nameplate	4
1.5.	Mode	Configuration	5
1.6.	Conne	ection Configuration	6
Chapter	II Produc	t Specification	7
2.1.	Basic	Specification	7
2.2.	IO Inte	erface Specification	8
Chapter	III Wiring	Communication Configuration & Network	9
3.1.	Ether	CAT Bus Interface	9
3.2.	Digita	I Inputs & Outputs	.11
	3.2.1.	Terminal Definition	.11
	3.2.2.	Digital Specification	.13
	3.2.3.	General Input Wiring	.14
	3.2.4.	General Output Wiring	.15
	3.2.5.	Wiring – IN as Encoder	.16
	3.2.6.	Wiring – OUT as PWM	.16
	3.2.7.	Wiring – OUT as Pulse	.17
3.3.	Whole	Wiring Reference	.18
Chapter	IV Expan	sion Module	.19
4.1.	Ether	CAT Bus Expansion Wiring	.19
4.2.	Ether	CAT Bus Expansion Resource Mapping	.20
Chapter	V Installa	ation Requirements	.23
5.1.	Install	ation Environment	.23
5.2.	Install	ation Size	.24
5.3.	Install	ment Method	.24
5.4.	Drive	Program Installation	.25
	5.4.1.	Unauthorized Version	.25
	5.4.2.	Authorized Version	.28
	5.4.3.	Ordinary Network Card Install EtherCAT Bus Protocol	.33
5.5.	Notes		.36
Chapter	VI Run aı	nd Maintain	.38
6.1.	Regula	ar Inspection and Maintenance	.38
6.2.	Comm	non Problems	.39

Chapter I Production Information

1.1.Production Introduction

XPCIE1032H economical motion control card is a kind of EtherCAT bus and pulse type that is with PCIE interface. It supports up to 64 axes motion control, which can achieve linear interpolation, any circular interpolation, space arc, helical interpolation, electronic cam, electronic gear, synchronous follow, virtual axis, robot, and all kinds of control requirements.

XPCIE series motion control card can be applied in high-speed and high-precision occasions, such as, semi-conductor equipment, SMT processing, 3C automation production line, new energy equipment, laser processing and non-standard automatic equipment.

1.2.System Framework

XPCIE motion control card is a kind of new type XPCIE bus motion control card. And multiple stepper motors or digital servo motors can be controlled. In addition, EtherCAT bus and ordinary pulse control are valid. What's more, it supports many functions, multiaxis point to point, interpolation motion, trajectory planning, handwheel control, encoder position checking, IO control, position latch, etc.

XPCIE1032H card requires CPU benchmark i5-4 generation 4 cores or above, main frequency not lower than 2GHZ, running memory above 8G, and hard disk above 256M.



1.3. Functional Features

- XPCIE1032H supports up to 64 axes motion control.
- Pulse output mode: single-ended direction / pulse.
- Support encoder position measurement, which can be configured as handwheel input mode.
- Maximum pulse output frequency of pulse axis is 500kHZ.
- 4096 isolated inputs and 4096 outputs can be expanded through EtherCAT bus.
- The maximum output current of general digital outputs can reach 300mA, which can directly drive some kinds of solenoid valves.
- Support linear interpolation, arbitrary circular interpolation, helical interpolation, and continuous interpolation.
- Support electronic cam, electronic gear, position latch, synchronous follow, virtual axis, and other functions.
- Support pulse closed loop, pitch compensation and other functions.
- Support multi-file and multi-task programming in ZBasic.

A variety of program encryption methods to protect the intellectual property rights of customers.

1.4. Model & Nameplate

XPCIE1032H-AX64-MO8-HW

	XPCIE1032H-AX64-MO0-HW
Mark	Product Interface
XPCIE	PCIE Interface
	XPCIE1032H-AX64-MO0-HW
Mark	Generation No.
1	Generation 1
	XPCIE1032H-AX64-MO0-HW
Mark	The Number of IO
032	32
	XPCIE1032H-AX64-MO0-HW
Mark	Meaning
Н	High-performance
	XPCIE1032H-AX64-MO0-HW
Mark	The Number of Axis
AX6	6-Axis
AX8	8-Axis
AX16	16-Axis
AX24	24-Axis
AX32	32-Axis
AX64	64-Axis
	XPCIE1032H-AX64-MO0-HW
Mark	Motion Control Functions
M00	Point to point
M02	Point to point, electronic cam, linear interpolation
MO8	Point to point, electronic cam, linear interpolation, circular interpolation,
	continuous interpolation

XPCIE1032H-AX64-MO0-HW		
Mark	Other Functions	
R	Robotic arm algorithm	
NC	NC, G code	
HW	Hardware comparison output	
ZV	Vision commands & functions	

1.5. Model Configuration

The description of the optional configuration of software functions is shown in the form below: including the selection of the number of axes, the selection of motion control functions, and the selection of other functions (PSO function, vision function, and manipulator function can be reselected).

Interface	Optional Functions	Definition Description
	Frame	R1: suit to ordinary robots
	Robot	R6: suit to 6-joint robots and special structure
		robots.
	NcGcode	NC: suit to NC G code function.
	ZVision	ZV: suit to vision instruction and function.
		HW: suit to HW hardware comparison output
	HW	function, refer to high-speed output channel
License Parameter		numbers selection.
		Select according to actual axes, the value set of
		axis needs to be larger than the number of axes
	Motor	used.
		AX4: 4 axes can be used at most.
		AX6: 6 axes can be used at most.
		AX8: 8 axes can be used at most.
		AX16: 16 axes can be used at most.
		AX24: 24 axes can be used at most.

	AX32: 32 axes can be used at most.
	AX64: 64 axes can be used at most.
	Valid motion control functions:
	MOO: point to point
	MO2: point to point, electronic cam, linear
Motion	interpolation.
	MO8: point to point, electronic cam, linear
	interpolation, circular interpolation, continuous
	interpolation.

1.6.Connection Configuration

External equipment / software configuration:

- > Main computer / industrial control computer, wired-mouse & keyboard.
- > Displayer
- Win10 operating system professional edition, ZDevelop development platform and operating system software of various machine tool industries, etc.

(note: users can download the latest RTSys (ZDevelop) version from the official website of Zmotion or contact us. Users who use other upper computer development platforms can also contact us to obtain function library files. And this product does not come with an operating system, and there is no built-in MotionRT software. Users need to go to the official website to download the MotionRT installation package)

Chapter II Product Specification

2.1. Basic Specification

ltem	Description	
Model	XPCIE1032H	
Basic Axes	6/8/16/24/32/64 axes, configure according to actual needs.	
Basic Axes Type	EtherCAT/Local Pulse axes	
HW	16 outputs can be configured as HW function.	
PWM	4 outputs can be configured as PWM function.	
Internal IO	16 inputs, 16 outputs (with overcurrent protection), and 8 are high-	
Internal IO	speed inputs, 16 are high-speed outputs.	
Max extended IO	4096 inputs and 4096 outputs.	
Pulse bit	64	
Encoder bit	64	
Speed accel bit	64	
Max pulse		
frequency	SUUKHZ	
VR power failure	2048	
storage space		
Power Supply	24V DC input	
Communication	EtherCAT	
interface		
Dimensions	90*106mm	
Work	10°C - 55°C	
temperature	- 10°C ~ 55°C	
Work humidity	10% ~ 95% (no condensation)	

PCIE doesn't support plug in and out when power on, please turn off the computer before plugging in and out the card. Please handle it carefully. Before touching the control card circuit or plugging in/out the control card, please wear anti-static gloves or touch an effectively grounded metal object to discharge the human body to prevent possible static electricity from damaging the motion control card.

2.2.10 Interface Specification

Item	Specification	Description	
Internal IO	16+16	16 inputs, 16 outputs (with overcurrent protection)	
Max extended IO	512 inputs, 512 outputs	Match with expansion module to expand IO	
High-speed input	8	IN0-7, 8 are high-speed inputs	
High-speed output	16	OUT0-15, 16 are high-speed outputs	
Latch input	4	4 can be configured as latch input, IN0-3	
Single-ended encoder	2	Input is reused, IN0-2, IN4-6	
PWM output	4	4 can be configured as PWM, OUT0-3	
Hardware comparison output	16	16 outputs can be configured as hardware comparison output (PSO function), and precision output can be compatible, OUT0-15.	
Single-ended pulse output	4	Output is reused, OUT8-15	
IO power input	DC24V	24 DC input, IO needs to be supplied by external power separately.	

Chapter III Wiring Communication Configuration & Network

3.1.EtherCAT Bus Interface

XPCIE1032H motion controller has a 100M EtherCAT communication interface, and it supports EtherCAT protocol. In addition, EtherCAT driver or EtherCAT expansion module can be connected.

\rightarrow Interface Definition

ECAT	PIN	Name	Description
	1	TX+	Send signal (+)
-	2	TX-	Send signal (-)
	3	RX+	Receive signal (+)
	4	NC	Reserved
	5	NC	Reserved
	6	RX-	Receive signal (-)
8	7	NC	Reserved
	8	NC	Reserved

\rightarrow Specification

Item	Specification
Communication protocol	EtherCAT protocol
Valid service	CoE(PDO, SDO), FoE
Curcheronization mathed	IO adopts input and output synchronization / DC-
Synchronization method	distributed clock
Physical level	100BASE-TX
Duplex mode	Full duplex
Topology	linear topology

Transfer media	Cable
Transfer distance	It is less than 100M between 2 nodes
Process data	Maximum 1486 bytes of one single frame
Synchronization shaking	alue.
of two slave stations	< Tus
Refresh	For 1000 digital input and output, about 30us.

→ Communication Cable Requirements

Both ETHERNET communication interface and EtherCAT communication interface adopt standard Ethernet RJ45 interface.

The network cable adopts Category 5e STP, and the crystal head has a metal shell to reduce interference and to prevent information from being eavesdropped. As shown below:



Item	Specification
Cable type	Flexible crossover cable, Category 5e
traverse	twisted pair
Line pairs	4
Isolation	cross skeleton
Connector	Crystal head with iron shell
Cable material	PVC
Cable length	Less than 100m

Use RJ45 network cable connection method:

- When installing, hold the crystal head that is with the cable and insert it into the RJ45 interface until it makes a "click" sound (kada).
- In order to ensure the stability of communication, please fix the cables with cable ties.
- When disassembling, press the tail mechanism of the crystal head, and pull out the

connector and the module in a horizontal direction.

Please use tube-type pre-insulated terminals and cables with appropriate wire diameters to connect the user terminals.

3.2. Digital Inputs & Outputs

General IO includes 16 inputs and 16 outputs (all are NPN types), when the number is not enough, expansion is valid. For IO, it needs to connect to 24V DC power externally.



3.2.1.Terminal Definition



PIN	Signal	Description Note		
1	E24V	IO power 24V input	IO power terminal to supply	
2	EGND	IO power ground / IO public end	power	
3	OUT0	Output 0, PWM0	1. All outputs are high-	
4	OUT1	Output 1, PWM1	speed outputs, default	
5	OUT2	Output 2, PWM2	are general outputs.	

6	OUT3	Output 3, PWM3	2. OUT0-3 can be		
7	OUT4	Output 4	configured as PWM		
8	OUT5	Output 5	output or pulse output		
9	OUT6	Output 6	through RTSys		
10	OUT7	Output 7	(ZDevelop).		
11	OUT8	Output 8, single-ended DIR3	3. OUT0-15 support		
12	OUT9	Output 9, single-ended PUL3	hardware comparison		
13	OUT10	Output 10, single-ended DIR2	output or precision		
14	OUT11	Output 11, single-ended PUL2	output.		
15	OUT12	Output 12, single-ended DIR1	4. OUT8-15 can be		
16	OUT13	Output 13, single-ended PUL1	configured as 4 pulse		
17	OUT14	Output 14, single-ended DIR0	outputs.		
18	OUT15	Output 15, single-ended PUL0			
19	E5V	E5V power output	Supply power for external		
20	EGND	E5V power ground / IO public end	equipment		
21	INO	Input 0, latch R0, encoder EA0	1. IN0-7 all are high-speed		
22	IN1	Input 1, latch R1, encoder EB0	inputs, default are		
23	IN2	Input 2, latch R2, encoder EZ0	general inputs.		
24	IN3	Input 3, latch R3	2. IN0-3 can be configured		
25	IN4	Input 4, encoder EA1	as latch input through		
26	IN5	Input 5, encoder EB1	RTSys (ZDevelop).		
27	IN6	Input 6, encoder EZ1	3. IN0-2 and 4-6 can be		
28	IN7	Input 7	configured as 2 encoder inputs.		
29	IN8	Input 8			
30	IN9	Input 9	which can connect to the		
31	IN10	Input 10	which can connect to the		
32	IN11	Input 11	elements		
33	IN12	Input 12			

34	IN13	Input 13
35	IN14	Input 14
36	IN15	Input 15

Note:

- Only 24V encoders can be used. The maximum pulse frequency of encoder 0 and encoder 1 is 500kHz, which can be connected to high-speed encoders, the others are common inputs, the maximum pulse frequency is 10kHz, and it can only be connected to low-speed encoders such as handwheels.
- The No. after inputting pulse output and encoder input is default axis No., and it can be switched into ordinary IO through ATYPE command (ATYPE = 0: ordinary IO, ATYPE = 1: pulse output, ATYPE = 3: encoder input, ATYPE = 4: pulse output + encoder input)

3.2.2. Digital Specification

\rightarrow High-speed Digital Output Specification

Item	High Speed Output	
Channel	16 (OUT0-OUT15)	
Output method	Transistor NPN type, OD outputs	
Output frequency	≤400kHz	
Voltage level	Load power ≤36V	
Max output current	+300mA	
Max leakage	25.14	
current when off	ΖομΑ	
Respond time to	1.up (registive load typical value)	
conduct		
Respond time to	240	
close	βμs	
Isolation method	Capacitive isolation	
Overcurrent	Support action surrant is 600m A	
protection	Support, action current is 600mA	

Respond time	Below 0.5ms
--------------	-------------

Note:

- The times in the form are typical based on the resistive load, and may change when the load circuit changes.
- Due to the leak-type output, the shutdown of the output will be obviously affected by the external load circuit, and the output frequency should not be set too high in the application.

\rightarrow Digital Input Specification

ltem	High-Speed Input (IN0-7)	Low-Speed Input (IN8-15)	
Input mode	NPN type NPN type		
Frequency	≤100kHz	≤5kHz	
Voltage level	DC24V (-15%~+20%)	DC24V (-15%~+20%)	
Current (typical value)	6.8mA	4.8mA	
The voltage to open	<15V	<14.5V	
Minimal current	2.3mA	1.8mA	
Impedance	3.3KΩ	4.7ΚΩ	
Isolation method	optoelectronic isolation	optoelectronic isolation	
Respond time	Below 10ms	Below 10ms	

Note:

- > There are high-speed inputs and low-speed inputs.
- The above parameters are standard values when the voltage of controller power supply (E+24V port) is 24V.

3.2.3. General Input Wiring

 \rightarrow Wiring Reference



\rightarrow Wiring Note:

- The wiring principle of high-speed digital input IN (0-7) and low-speed digital input IN (8-15) is shown in the figure above. The external signal source can be an optocoupler, a key switch or a sensor, etc., all can be connected as long as the requirements on output of electric level can be achieved.
- For the public end, please connect the "EGND" port on the power supply to the "COM" terminal of the external input device.

3.2.4. General Output Wiring



\rightarrow Wiring Reference

\rightarrow Wiring Note:

- The wiring principle of high-speed digital output OUT (0-15) is shown in the figure above. The external signal receiving end can be an optocoupler or a relay or solenoid valve, all can be connected as long as the input current does not exceed 300mA.
- For the connection of the public end, please connect the "EGND" port on the IO power supply to the negative pole of the DC power supply of the external input device.

3.2.5. Wiring - IN as Encoder

There are 2 24V single-ended encoder inputs on board for XPCIE1032H.

Here, use IN4-6 to connect to encoder, when wiring is done, IN can be used as encoder input signal through ATYPE (1) = 3. IN4 is EA1, IN5 is EB1, IN6 is EZ1, and corresponding encoder axis No. is 1.



3.2.6. Wiring - OUT as PWM

Please use OUT that supports PWM function, OUT0~OUT3 can be selected.



3.2.7. Wiring – OUT as Pulse

There are 4 single-ended pulse outputs on board for XPCIE1032H.

Here, use OUT8 and OUT9 to connect to driver, when wiring is done, when OUT8 and OUT9 are configured through ATYPE (3) = 1. OUT 8 is DIR3, OUT9 is PUL3, and corresponding pulse driver axis No. is 3.

E24V or E5V can be used according to specific driver.



3.3.Whole Wiring Reference



Chapter IV Expansion Module

The control card can expand digital IO, analog AD/DA, pulse axis and other resources through EtherCAT bus expansion module or ZMIO310-ECAT series vertical bus expansion module.

The EIO expansion modules and ZMIO310-ECAT are expansion modules used by the EtherCAT bus controller. For example, EIO series can expand the resources of digital IO and pulse axis. When the resources of the controller are insufficient, the EtherCAT bus controller can be connected to multiple EIO expansion modules for expansion, you can view the maximum number of IO expansion points and the maximum number of expansion axes of the controller, and in this way, it supports IO remote expansion.

4.1. EtherCAT Bus Expansion Wiring

After the expansion wiring is completed, each EIO expansion module does not need to develop again. It only needs to manually configure the unique IO address and axis address in the EtherCAT master controller, and it can be accessed after the configuration is completed.

The IO address number is set through the bus command NODE_IO, and the program on the controller can access the resources on the expansion module only through the IO number. The configuration of the axis address uses the AXIS_ADDRESS command to map axis number, and when the binding is completed, specify the axis number through the BASE or AXIS command.

When wiring, pay attention that EtherCAT IN is connected to the upper-level module, and EtherCAT OUT is connected to the lower-level module. The IN and OUT ports cannot be mixed.



Involved number concepts in above figure are as follows: the bus-related command parameters will use the following numbers:

Slot number (slot):

The slot number refers to the number of the bus interface on the controller, and the slot number of the EtherCAT bus is 0.

Device number (node):

The device number refers to the number of all devices connected to a slot. It starts from 0 and is automatically numbered according to the connection sequence of the devices on the bus. You can view the total number of devices connected to the bus through the NODE_COUNT(slot) command.

Drive number:

The controller will automatically identify the drive on the slot, and the number starts from 0, and the number is automatically numbered according to the connection sequence of the drive on the bus.

The drive number is different from the device number. Only the drive device number on the slot is assigned, and other devices are ignored. The drive number will be used when mapping the axis number.

4.2. EtherCAT Bus Expansion Resource Mapping

\rightarrow IO Mapping:

The program on the controller can access the resources on the expansion module only through the IO number. The IO number of the EtherCAT bus expansion module is set through the bus command NODE_IO, and the input and output are configured at the same time.

When IO mapping, first check the maximum IO number of the controller itself (including the external IO interface and the interface in the pulse axis), and then use the command to set.

If the extended IO coincides with the IO number of the controller itself, the two will work at the same time, so the mapped number of the IO mapping must not be repeated in the entire control system.

IO mapping syntax:

NODE_ IO(slot, node) = iobase

slot: slot number, 0-default

node: device number, starting from 0

iobase : mapping the IO start number, the setting result will only be a multiple of 8 **Example:**

NODE_IO(0,0)=32 'set the IO start number of slot 0 interface device 0 to 32 If device 0 is EIO16084, after configuration according to the above syntax, the IO numbers corresponding to input IN0-15 are 32-47 in turn, and the IO numbers corresponding to OUT0-7 are 32-39 in turn.

0	41bh	1918h	0	4	24(32-55)	16(32-47)	0
<							>

\rightarrow AXIS Mapping:

Before using the axis of the expansion module, you need to use the AXIS_ADDRESS command to map the axis number, and the axis mapping also needs to pay attention to the axis number of the entire system cannot be repeated. The mapping syntax of the EIO series extended axis is the same as that of the bus driver.

Axis mapping syntax:

AXIS_ADDRESS(axis number)=(slot number << 16)+driver number+1

Example:

AXIS_ADDRESS(0)=(0<<16)+0+1

'the first drive on the EtherCAT bus, drive number 0, bound as axis 0 AXIS_ADDRESS(1)=(0<<16)+1+1 'the second drive on the EtherCAT bus, drive number 1, bound as axis 1 If the first node is EI016084, and EI016084 is connected to drive, then driver 0 here is the first pulse driver connected to EI016084, otherwise it is the EtherCAT driver.

Chapter V Installation Requirements

5.1.Installation Environment

Environment temperature: the ambient temperature has a great impact on the life of the device, and the operating environment temperature of the device is not allowed to exceed the allowable temperature range (-10°C to 55°C).

Please install it in a place that is not easy to vibrate. Vibration should not be greater than 4.9m/s². Take special care to stay away from equipment such as punch presses.

Avoid placing in direct sunlight, humidity, and water drops.

Avoid installing in places with corrosive, flammable and explosive gases in the air.

Avoid installing in places with oil and dust, the pollution level of the installation place is PD2.

This product is installed in the cabinet and needs to be installed in the final system. The final system should provide corresponding fireproof enclosures, electrical protection enclosures, and mechanical protection enclosures, etc., in compliance with relevant IEC standards.

Item		Parameters	
Work Temperature		-10℃-55℃	
Work rela	ative Humidity	10%-95% non-condensing	
Storage Temperature		-40 $^\circ \text{C} \sim$ 70 $^\circ \text{C}$ (not frozen)	
Storage Humidity		Below 90%RH (no frost)	
Frequency		5-150Hz	
vibration	Displacement	3.5mm(directly install)(<9Hz)	
	Acceleration	1g(directly install)(>9Hz)	
	Direction	3 axial direction	
Shoo	k (collide)	15g, 11ms, half sinusoid, 3 axial direction	

CPU heat dissipation should be considered when the chassis is fully enclosed and there is no air circulation.

Degree of Protection	IP20
----------------------	------

5.2. Installation Size



The card slot is designed according to PCIE*1, but actually it is compatible with PCIE*1 to PCIE*6.

5.3.Installment Method

- 1. Turn off the power to the computer.
- 2. Open the computer case, select a free XPCIE card slot, and use a screwdriver to remove the corresponding baffle strip.
- 3. Insert the motion control card into the slot securely, and tighten the fixing screws on the baffle strip.

5.4. Drive Program Installation

The driver of the test version is not signed, and it can be installed only after pressing F8 when Windows starts to disable the driver signature authentication. The signed version does not need to disable the signature.

5.4.1.Unauthorized Version

When there is no PCI card device, in the device manager, the menu: "Operation" - "Add Obsolete Hardware", if there is no "Operation", right click.

1. Find "Add Obsolete Hardware".



2. Select "Manual", click "next".

添加硬件
这个向导可以帮助你安装其他硬件
这个向导可以搜索其他硬件并为你自动安装。或者,如果你知道要安装哪个型号的硬件,你 可以从列表选择。
你想向导做什么?
○ 搜索并自动安装硬件(推荐)(S)
● 安装我手动从列表选择的硬件(高级)(M)
< 上 一步 (B) 下一页(N) > 取消

3. Select "next".

添加硬件	
从以下列表,选择要安装的硬件类型	
如果看不到想要的硬件类型,请单击"显示所有设备"。	
常见硬件类型(H):	
显示所有设备	^
■ IDE ATA/ATAPI 控制器	
□ IEEE 1284.4 兼容打印机	
□ IEEE 1284.4 设备	
IEEE 1394 主控制器	
🚔 IEEE 1667 接收器和控制设备	
🛄 Media Center Extenders	
Miracast 显示设备	
♀ OPOS 旧设备	¥
< 上一步(B) 下一步(N) >	取消
	-Vdra

4. Choose to install from disk, (all options are default items, no need to choose

manufacturer and model)

添加硬件 选择要为此硬件安装的设备驱动程序
请选定硬件设备的厂商和型号,然后单击"下一步"。如果手头有包含要安装的驱动程序的磁盘, 请单击"从磁盘安装"。
「商 「 (IEEE 1667 兼容 ACT) (IEEE 1667 兼容接收器) (Standard system devices) (标准 MTP 设备) ▲
○ 这个驱动程序已经过数字签名。 告诉我为什么驱动程序签名很重要 < 上一步(B)

5. Select the driver directory and click OK.

从磁盘安装	ŧ	×
	插入制造商的安装盘,然后确定已在下面选定正确的驱动 器。	确定取消
	制造商文件复制来源(C): F:\RT710\RT版本迭代\rt0924_signed2\driver_signe 、	浏览(B)

6. If there is ZMotionRT Controller in the device manager, the installation is successful. If no, right click any device, and select "scan to detect hardware changing". Fail to install, restart the PC, and scan again to install again.

5.4.2. Authorized Version

It is used with the card.

Method 1: install automatically

Use the built-in installation wizard software dpinst_amd64.exe in the driver directory to automatically install, and the specific operation is according to the software guide.



Note: If there is no PCI device, the software cannot be installed successfully, only the ZMotionRT64.sys file can be installed! !

Method 2: install manually

1. Open the Device Manager menu and select the PCI device in Other Devices.



2. If there are multiple PCI devices, right-click "Properties" to view detailed information, select "Hardware ID" for properties, and confirm that it is a PCI device starting with PCI\VEN_EF34&DEV_1000&.

PCI 设备 属性	×
常规 驱动程序 洋细信息 事件 资源	
PCI 设备	
厚性(P)	
硬件 Id	\sim
值(A) PCI/VEN_EF34&DEV_1000&SUBSYS_1000EF34&REV_37	
PCI\VEN_EF34&DEV_1000&SUBSYS_1000EF34 PCI\VEN_EF34&DEV_1000&CC_123612	
PCI\VEN_EF34&DEV_1000&CC_1236	
確定	取消

3. Find PCI Device, right-click to select "update drive program".



4. Select "browse my PC to check drive program".



5. Click "browse", and select driver folder.

		×
÷	▋ 更新驱动程序 - PCI 设备	
	浏览计算机上的驱动程序	
	在以下位置搜索驱动程序:	
	D:\rt1118\driver	
	☑包括子文件实(I)	
	broswe	
	→ 让我从计算机上的可用驱动程序列表中选取(L) 此列表将显示与该设备兼容的可用驱动程序,以及与该设备属于同一类别的所有驱动程序。	
	下一步(N) 取	消

6. Click "next step".



7. Wait until installed, click close.



8. If there is ZMotionRTController in the device manager, the installation is successful.



5.4.3. Ordinary Network Card Install EtherCAT Bus Protocol

1. On the Windows network connection interface, select the network port that needs to be used as the bus, right-click Properties->Installation->Protocol->Add.



📱 以太网 属性	──
网络	选择网络功能类型 X
连接时使用:	单击要安装的网络功能类型(C): ● 容户端 ● 服务 ● 协议 ● 描述
••••••	卸载(U) 属性(R)

2. Select "installation from disk".

单击你想安装的]网络协议,然后单击"确定"。如果你 奏"。	有这个功能的安装磁盘,	请
厂商 <mark>Microsoft</mark> ZMotion Corp.	网络协议: □ 可靠多播协议		
这个驱动程序已经过 告诉我为什么驱动程	数字签名。 <u>字签名很重要</u>	从磁盘安装(H)	•••

3. Brower drive position, select "ZMotionRtPacket.inf".

🔮 查找文件					×
查找范围(I):	driver		-) 📂 💷 🔻	
8	名称	^		修改日期	
長に使用的で同	已签名			2022/7/12 8:34	8
殿江区市的坝口	ZMotionR	t64.inf		2022/7/3 18:3	1
	ZMotionR	tPacket.inf		2022/5/29 18:	11
桌面	-				
文档					
此电脑					
学	<			-	>
Matt	文件名(N):	ZMotionRtPacket.inf		~ 打	开(0)

4. Click "ok".

从磁盘安装		×
	插入制造商的安装盘,然后确定已在下面选定正确的驱动 器。	确定 取消
	制造商文件复制来源(C): F:\RT710\RT版本迭代\rt0924_signed2\driver_signe >	浏览(B)

Note: The installation wizard software cannot install this agreement! !

If there is ZMotionRT64PacketProtocolDriver in the properties, it means the installation is successful, and you can add the corresponding network port bus protocol if you check it. The network port that does not connect to the device can be unchecked here.

🖗 本地波	连接 属性		\times
网络	共享		
连接时	使用:		
7	Realtek PCIe GbE Family Controller		
	配置(0	.)	
此连接	使用下列项目(O):		
	∎ Internet 协议版本 4 (TCP/IPv4)	^	
	L Microsoft 网络适配器多路传送器协议		
☑ _	L Microsoft LLDP 协议驱动程序	- 64	
	⊾Internet 协议版本 6 (TCP/IPv6)		
	. 鲜蜂层拓扑发现响应程序		
☑ _	ZMotionRT64 Packet Protocol Driver		
	▲ 链路层和扑发现映射器 I/O 驱动程序		
		~	
		1	1
	安装(N) 卸载(U) 属性(R)	
+++>+			
1817		_	
允许	并其他计算机使用 Microsoft 网络访问你计算机上的资源		
			_
	确定	取消	

5.5.Notes

- Be sure to pay attention to anti-shielding treatment during application, please use special anti-shielding wires for wiring.
- If the scan fails, try to use the cycle scan until it is successful and then turn it on. It usually occurs when the device is powered on or the first scan of the device is added or removed.
- If the scanning device is successful but the number of devices is 0, please first check whether the slot number matches, if the slot number is correct and still fails, please try stop to stop ZMotionRT7 and start ZMotionRT7 again.

- If there is strong interference on site, the bus may lose packets for a short time as the interference intensity of the equipment increases. After continuous packet loss, the motor may stop or the drive may report an error. Power off and restart to restore. The packet loss can be checked by ZTEST(60,3,0) for the dedicated port, and the interruption can be checked by ZTEST(61,1), and the non-dedicated port can be checked by the bus packet capture tool.
- To troubleshoot the failure caused by interference, you can try to stop the ZMotionRT7 without power supply and then re-run the download program. If an error occurs, it means interference. Or check whether the network port network becomes unconnected.
- Please deploy the application environment under the specified number of devices.
 Scan exceptions or other error reports may occur after exceeding the specifications.

Chapter VI Run and Maintain

6.1. Regular Inspection and Maintenance

The working environment has an impact on the device. Therefore, it is usually inspected regularly based on the inspection cycle of 6 months to 1 year. The inspection cycle of the device can be appropriately adjusted according to the surrounding environment to make it work within the specified standard environment.

Check item	Check content	Inspection standards
		Confirm whether the power
		distribution cabinet is powered off.
	Whether there is	Use a vacuum cleaner to remove
Whole machine	accumulation of garbage,	garbage or dust to avoid touching
	dirt and dust on the surface.	the parts, if the surface dirt cannot
		be removed, wipe it with alcohol and
		let it dry and evaporate completely.
	Whether the power line and	Replace cracked cables
Cable	connection are discolored.	replace damaged connection
Cable	Whether the insulation layer	terminals
	is aged or cracked.	
	Whether the suction is not	
	firm or makes abnormal	
Electromagnetic	noise during the action.	
contactor	whether there is a short	Replace abnormal components.
peripheral	circuit, water contamination,	
	expansion, or rupture of	
	peripheral devices	
	Whether the air duct and	Clean the air duct
Air duct vent	heat sink are blocked.	Change the fan
	Whether the fan is damaged.	
	Whether the control	Clean the foreign objects on the
Control circuit	components are with poor	surface of control lines and
	contact.	connection terminals.
	Whether the terminal screws	Replace damaged and corroded

are loose.	control cables.
Whether the control cables	
have insulation cracks.	

6.2. Common Problems

Problems	Suggestions	
	1. Check whether the ATYPE of the controller is cor	rect.
	2. Check whether hardware position limit, softw	ware
	position limit, alarm signal work, and whether	axis
	states are normal.	
	3. Check whether motor is enabled successfully.	
	4. Confirm whether pulse amount UNITS and sp	beed
Matar daga pat ratata	values are suitable. If there is the encoder feedb	ack,
Motor does not rotate.	check whether MPOS changes.	
	5. Check whether pulse mode and pulse mode of c	drive
	are matched.	
	6. Check whether alarm is produced on mo	otion
	controller station or drive station.	
	7. Check whether the wiring is correct.	
	8. Confirm whether controller sends pulses normal	ly.
Controller worke normally	1. Check whether the connection between driver	and
controller works normally,	motor is correct, and whether the wiring betw	veen
and pulses are sent	driver and controller is good contact.	
normaliy, but motor	2. Please ensure driver works normally, no war	ning
doesh i fotate.	appeared.	
	1. Check whether set deceleration and speed exc	ceed
	the equipment limit.	
	2. Check whether output pulse frequency exce	eeds
Motor can rotate, but it	driver receive limit.	
works abnormally.	3. Check whether controller and driver are grour	nded
	correctly, and whether anti-interference is well d	one.
	4. The current limiting resistor used in the photoele	ctric
	isolation circuit of the pulse and direction si	gnal

		output is too large, but the working current is too
		small.
It can control motor, but motor appears vibration or overshoot.	1.	Driver parameter configuration may be incorrect,
		check driver parameters.
	2.	Set improper acceleration and deceleration time and
		motion speed.
No signal comes to the input.	1.	Check whether the limit sensor is working normally,
		and whether the "input" view can watch the signal
		change of the limit sensor.
	2.	Check whether the mapping of the limit switch is
		correct.
	3.	Check whether the limit sensor is connected to the
		common terminal of the controller.
The output does not work.	1.	Check whether IO power is needed.
	2.	Check whether the output number matches the ID of
		the IO board.
	1.	Whether net port led is ON?
	2.	Whether DC net cable is used but PC doesn't support
Fail to connect controller		automatic wiring.
to PC through net port.	3.	Whether controller IP address is modified.
	4.	Whether IP address of PC network card and
		controller are in the same network segment.
XPCIE card can not be found.	1.	Whether specified drive is installed.
	2.	Is the XPCIE card inserted properly and the baffle is
		fixed with screws?
	3.	Is the XPCIE card inserted before the computer is
		turned on?