



# Teach Pendant HMI


ZHD500XB




Vision Motion  
Controller



Motion  
Controller



Motion  
Control Card



IO Expansion  
Module



HMI

## Statement

Thank you for choosing our Zmotion products. Please be sure to read this manual carefully before use so that you can use this product correctly and safely. Zmotion is not responsible for any direct or indirect losses caused by the use of this product.

The copyright of this manual belongs to Shenzhen Zmotion Technology Co., Ltd. And reproduction, translation, and plagiarism of any content in this manual in any form is strictly prohibited without the written permission of Zmotion.

The information in this manual is for reference only. Due to design improvements and other reasons, Zmotion reserves the right of final interpretation of this information! Contents are subject to change without prior notice!

## ➤ Notes

In order to prevent possible harm and damage caused by incorrect use of this product, the following instructions are given on matters that must be observed.

### ■ Danger

Do not use it in places with water, corrosive or flammable gases, or near flammable substances.	May cause electric shock, fire, damage, etc.
When installing or disassembling, make sure the product is powered off.	
Cables should be connected securely, and exposed parts that are energized must be insulated by insulators.	
Wiring work must be performed by professionals.	

### ■ Notes

It should be installed within the specified environmental range.	May cause damage, mis-operation, etc.
Make sure there are no foreign objects on the product hardware circuit board.	
After installation, the product and the mounting bracket should be tight and firm.	
After installation, at least 2-3cm should be left between the product and surrounding components for ventilation and replacement.	
Never disassemble, modify, or repair it by yourself.	

# Content

Chapter I Production Information.....	4
1.1.    What is ZHD500XB.....	4
1.2.    ZHD500XB Specification Parameters.....	5
1.3.    ZHD500XB Size .....	6
1.4.    System Configuration.....	7
1.5.    Operation Method.....	7
1.6.    Order Information .....	8
Chapter II ZHD500XB Appearance .....	9
2.1.    Whole Layout.....	9
2.2.    Touch Screen Points Coordinates.....	10
2.3.    Hardware Interfaces.....	10
Chapter III Usage & Operations .....	16
3.1.    Physical Key Codes .....	16
3.2.    Touch Correction .....	18
3.3.    Operation Steps.....	19
3.4.    How to Use Physical Encodes.....	20
Chapter IV Maintain.....	24
4.1.    Regular Inspection and Maintenance .....	24
4.2.    Common Problems.....	25

# Chapter I Production Information

## 1.1. What is ZHD500XB

ZHD500XB is one touch screen teach pendant that can show by network. Please note it must be used together with the controller that support **ZHMI** function.

This teach pendant has one DC24V power supply, and its screen is true color with a resolution of **1024\*600**. And there are 16 buttons, one emergency stop switch, key selection switch, and one handwheel (can be pressed).



- Through communicating with controller scripts, show and operate all kinds of interfaces.
- Support drawing: Chinese & English characters, line, arc, image.
- With emergency stop button, key selection switch, handwheel.
- There are 16 key buttons, key functions can be customized.
- Support RJ45 crystal head, U disk interface.
- Support HMI configuration protocol.
- It can control all kinds of manipulator control
- Support touch screen, which can be used together with buttons, including, the stylus.
- Resolution: 1024\*600

- Good looking and more comfortable operation.

ZHD HMI is a kind of open teach pendant that is with touch screen. It develops interface program by RTBasic, RTHmi, RTHmi languages in RTSys. And it can debug online.

## 1.2. ZHD500XB Specification Parameters


### --Product Parameters--

Item	Description
Resolution	1024*600
Touch Screen Size	10.1" TFT LCD
Brightness	320 cd/m <sup>2</sup>
Color	24-bit
Touch Screen	Resistive touch screen
EtherNET	100 Base-T


### --Other Parameters--

Item	Description
Power Supply	DC24V
Max Power Consumption	2.4W
Size	312mm*236mm*107mm
Weight	1612g
Work Temperature	0 to 50°C
Storage Temperature	-20 to 60°C

### 1.3. ZHD500XB Size



## 1.4. System Configuration



## 1.5. Operation Method

### --Operation Recommendation--

Generally, operate the teach pendant by "handheld". If you use right-hand to operate usually, please hold it using your left-hand, then operate the button and the touch screen by your right-hand, like below shown:



### --Other Operations--


- Two hands do that.
- Put it on the platform, then operate.
- Make it on the wall, then operate.

## 1.6. Order Information

Item	Model	Specification Description
HMI	ZHD500XB-0L30	3-meter connecting line (without robot ENABLE button)
HMI	ZHD500XB-1L30	3-meter connecting line (with robot ENABLE button)

# Chapter II ZHD500XB Appearance

## 2.1. Whole Layout




No.	Interface	Description
①	Key Selection Switch	Switch mode I / mode 2 / mode II.
②	Emergency Stop Button	Press it, axis will stop, if you want to cancel "emergency stop" state, rotate the button clockwise.
③	ON / Pause Button	Press "ON" to run program. Press "Pause" to pause the program
④	Axis Shift Button	Used together with physical key encodes
⑤	Function Button	Used together with physical key encodes
⑥	Display screen (touch screen)	Touch screen of 1024*600 resolution / 10.1-inch TFT display screen.
⑦	USB	Reserved
⑧	Handwheel	Rotary encoder, can rotate forward, rotate inversely, press.
⑨	Handheld	There are several handheld methods, as you needed.

⑩	Enable	Default it doesn't support, you can order.
⑪	Stylus	Used to click the touch screen.
⑫	State Led	S1: reserved, can be customized.
		S2: reserved, can be customized.
		S3: reserved, can be customized.
		Power Led: it is ON when power is conducted normally.
		Run Led: it is ON when the program runs normally
		Error Led: it is ON when the program runs abnormally.

## 2.2. Touch Screen Points Coordinates

It is 1024\*600, the coordinate origin is at upper left corner.



## 2.3. Hardware Interfaces


ZHD500XB has 16 buttons, used together with physical button encodes, for the button function, which can be customized.

Please refer to physical codes in "Chapter III Usage & Operation" and physical buttons in RTHmi.

### --Power Interface--

ZHD500XB uses 24V DC power.

There are 3 cables on the network crystal head, HMI power cable, and emergency stop signal cable. Red one is 24V power +, black one is 24V power -:



## --RJ45 Crystal Head--

### A. Specification

PIN Definition			Item	Description
	PIN	Signal	Description	
	1	RT+	Receive Signal (+)	Communication protocol
	2	RX-	Receive Signal (-)	Communication velocity
	3	TX+	Send Signal (+)	Default IP
	4	NC	Reserved	Communication cable
	5	NC	Reserved	Category 5e STP
	6	TX-	Send Signal (-)	
	7	NC	Reserved	
	8	NC	Reserved	Cable length
				Best <10m

### B. How to do Wiring

- HMI can be connected to controller (point to point) by one category 5e STP (shielded twist-pair) cable.
- HMI also can be connected to interchanger. That is, expand ethernet channels to connect to other devices by interchanger, then achieve one-multiple connection.

### C. How to Use

- 1) After wiring and power on, connect HMI to controller / RTSys through ethernet.
- 2) Check HMI IP. HMI IP, controller IP, and PC IP should in same network segment, you can modify it through IP\_ADDRESS command.
- 3) Details of above command and other commands, please refer to Basic Programming Manual.


### **--U Disk Interface--**

This interface's function is reserved.

### **--Key Selection Switch--**

You can switch the mode through rotating the switch. The switch locates in upper left.

There are 3 modes, when you selected one, one "kada" sounds indicates the state. And the key can be removed in each position.




Mode	Description
Mode I	Customized function
Mode 0	Customized function
Mode II	Customized function

### **--Emergency Stop--**

This button is located at upper right corner of HMI. When some emergency situations happen, you can press it to protect the program, axis will stop immediately. When all is

normal, you can rotate the button clockwise to cancel it.



**Note:** please consider the "Circuit Design", which must be safe and reliable, otherwise, hard to achieve emergency stop. And the stop button on the teach pendant can't replace the emergency stop button and other safe devices.

## --Board Buttons--

It located in two sides of HMI forward, functional keys and axis shift keys.

**ON / STOP**


**Axis Shift**

**Function Key**

Buttons	Description
ON	Run Program
STOP	Stop Program
X- X+	Axis Shift (Motion) Buttons
Y- Y+	
Z- Z+	
Rx- Rx+	
Ry- Ry+	
Rz- Rz+	
F1-F2	Function Button


## --Handwheel (Rotary Encoder)--

The handwheel (rotary encoder) locates in teach pendant's right side, supporting forward turn, inverse turn and press down.




### --Enable (Optional Order)--


In right side of the teach pendant cover, enable button can be installed. Therefore, this teach pendant doesn't have the ENABLE button by default.



### --Stylus--

Recommend you connect the stylus and the teach pendant by one line, like below.





# Chapter III Usage & Operations

## 3.1. Physical Key Codes

Encodes of button consist of row and column combination.

When the button is pressed, HMI will automatically send the physical button to the controller, then controller can detect the physical button. If you need to use virtual keys, there is one Key transformation list in RTSys – HMI.

**Note:** for customized one or others, please contact us, because different positions are with different values.

### --Mode Selection Switch--

Button	Button Encode
Mode I	1
Mode 0	No fixed encode
Mode II	2

### --Emergency Stop--

Button	Button Encode
Emergency Stop	5

### --Board Buttons--

Button	Button Encode
ON	Global Const ON = 3
STOP	Global Const STOP = 4
F1-F2	Global Const key_f1 = 11 'functional key F1 Global Const key_f2 = 12 'functional key F2
X- X+	Global Const key_X+ = 24 'axis shift key Global Const key_X- = 25 'axis shift key
Y- Y+	Global Const key_Y+ = 34 'axis shift key

	Global Const key_Y- = 35 'axis shift key
Z- Z+	Global Const key_Z+ = 44 'axis shift key
	Global Const key_Z- = 45 'axis shift key
Rx- Rx+	Global Const key_Rx+= 54 'axis shift key
	Global Const key_Rx-= 55 'axis shift key
Ry- Ry+	Global Const key_Ry+ = 64 'axis shift key
	Global Const key_Ry- = 65 'axis shift key
Rz- Rz+	Global Const key_Rz+= 74 'axis shift key
	Global Const key_Rz- = 75 'axis shift key

**Do not remove the film without permission, as this may cause loose sealing, damage to the buttons, etc.!!!**

## --Handwheel--

The rotary encoder in the right side of teach pendant is the handwheel, you can forward turn, reverse turn, and press down.

Each one circle, 20 pulses will be sent.

While using the handwheel, set ATYPE as 24 (remote encoder axis type). Controllers should be 5XX series with the firmware of 20180401 or above.


Button	Button Encode
Handwheel	8

**The handwheel cap is an easily damaged item. If the teaching box accidentally falls to the floor, please check the condition of the handwheel cap!!!**

## --Enable (Optional Order)--

There are 3 buttons of the switch, and each position has corresponding physical code:

Button	Function	Switch Motion	Switch Contact	Key Code
1	Origin position	No	OFF	No
2	Enable	Press	ON	6 & 7
3	Disable	Full press	OFF	



➤ **How to Use?**

Step 1: when the ENABLE button is in full release state, the natural state is key 1, and the robot is not enabled, in this situation, can't operate.

Step 2: gently hold the enable key (located on the right side of the teaching box), which is now the second key position, and the robot is enabled (a "click" sound is heard). Then you can perform manual operation (keep pressing the enable key). **The contact state is: OFF → ON (a).**

Step 3: continue to press hard, which is now the third key position, and the robot is disabled (a "click" sound is heard). **The contact state is: ON → OFF (b).**


Step 4: when in the third key position, completely release the key and return to the first key position, and the robot remains in the disabled state (a "click" sound is heard). **The contact state is: OFF → OFF (c).**

Step 5: When in the second key position, release the key and return to the first key position, and the robot is disabled. **The contact state is: ON → OFF (d).**

## 3.2. Touch Correction

➤ **Method 1**

Click continuously in a "Z-shaped" manner (upper left, upper right, lower left, lower right, upper left, upper right, lower left, lower right) until the settings window pops up to wake up the screen. You can perform touch calibration (Touch Adjust), controller IP modification, speaker (Speaker On) operations, etc.



#### ➤ **Method 2**

After connected to RTSys, trigger correction by TOUCH\_ADJUST command.

Follow the English instructions on the display (Touch crosshair to calibrate), trace the "cross" icon on the screen and click on it one by one.

### **3.3. Operation Steps**

#### **--Connect to Power--**

Please refer to above [power interface](#), red & DC24V +, black & DC24V -.

#### **--Touch Calibration--**

Please refer to above ["Touch Correction"](#).

#### **--Connect to Controller--**

##### ➤ **Method 1: connect HMI and controller directly, then HMI identifies controller IP.**

- 1) Connect controller and PC by serial / ethernet. And connect controller to RTSys / ZDevelop, then download the program into ROM. After that, disconnect controller and PC.
- 2) Use network cable to connect HMI and controller. When communicating by ethernet, please make sure HMI IP and controller IP are in same network segment. If not, you need to modify controller IP (controller default is 192.168.0.11, HMI default IP is

192.168.0.10)

- 3) Do touch calibration: after powering on, you can click the four corners of the screen of the teaching box in a Z-shaped order twice in a row to wake up the screen and pop up the setting window.
- 4) In popped window, it will automatically obtain connected controller IP address, select needed correct IP, then click "Connect".

**Note: if HMI doesn't scan controller IP by method 1, please refer to method 2.**

➤ **Method 2: connect HMI to PC at first, then do connection of HMI and controller.**

- 1) Use interchanger to connect HMI, controller, and PC (you can view "[system configuration](#)", make sure their IP addresses are in same segment).
- 2) Connect controller to RTSys / ZDevelop, then download the program into ROM. After that, disconnect.
- 3) Do touch calibration: after powering on, you can click the four corners of the screen of the teaching box in a Z-shaped order twice in a row to wake up the screen and pop up the setting window.
- 4) Connect HMI and RTSys / ZDevelop (HMI IP and PC IP are in same network segment).
- 5) In RTSys / ZDevelop "output" window, send IP\_CONNECT = controller IP command. Then, HMI will show HMI interface content, which means HMI and controller are connected successfully.
- 6) If you want HMI program to update in real-time. After step 5, disconnect HMI with RTSys / ZDevelop, then connect controller to RTSys / ZDevelop, at this time, connect them (controller & PC & HMI) through interchanger. When the program changed, download the program into controller, in this way, real-time can be achieved.

**For RTSys/ ZDevelop, it also can simulate this HMI.**

### 3.4. How to Use Physical Encodes

By binding this component to the physical buttons of the HMI, customized physical button

actions can be achieved.

## --How to Use--

Click RTSys / ZDevelop “Control Class” – “Control” – “Key button”, then put this component to suitable position, open the component's property window, find “Bind PhyKey”, and select needed one. Then in “action”, choose needed actions. In this way, you can achieve corresponding actions by real hardware button, that is, you bind it with one button of physical key, actions selects “call sub”, when you pressed the HMI button, it will call corresponding sub function.

### ➤ Example 1

- 1) Bind “run” control with “ON” physical button. In HMI file, click “run” control, then in its property window, bind it with “3” (3 is HMI “ON” button).

Bind “pause” control with “pause” physical button. In HMI file, click “pause” control, then in its property window, bind it with “4” (4 is HMI “pause” button).



- 2) Download the program again to run it. Set “custom parameter”, and after selecting the axis, you can use “ON” “pause” buttons on HMI to replace touch screen button, that is, control selected axis' motion. In touch screen “motion state” window, you can view current axis' position and speed.



## ➤ Example 2

1) Bind “+” control with “X+” physical button. Click “motion control” window “+” of manual, then in its property window, bind it with “24” (24 is HMI “X+” button).

Bind “-” control with “X-” physical button. Click “motion control” window “-” of manual, then in its property window, bind it with “25” (25 is HMI “X-” button).



2) Download the program again to run it. Set “custom parameter”, and after selecting the axis, you can use “X+” “X-” buttons on HMI to replace touch screen X+ & X- buttons, that is, control selected axis' forward and reverse motion. In programming design, this movement is a triggered movement, that is, when an external force is applied (such as pressing a button), the movement will be started, and when the external force is removed (such as releasing the button), the movement will stop. In touch screen “motion state” window, you can view current axis' position and speed.



# Chapter IV Maintain

The correct operation and maintenance of the device can not only guarantee and extend the life cycle of the equipment itself, but also take technical management measures according to the pre-specified plan or the corresponding technical conditions to prevent equipment performance degradation or reduce equipment failure.

## 4.1. Regular Inspection and Maintenance

The working environment has an impact on the device. Therefore, it is usually inspected regularly based on the inspection cycle of 6 months to 1 year. The inspection cycle of the device can be appropriately adjusted according to the surrounding environment to make it work within the specified standard environment.

Check item	Check content	Inspection standards
power supply	Check whether the voltage is rated	DC 24V ( -5%~5% )
surroundings	Whether the ambient temperature is within the specified range (when installed in the cabinet, the temperature inside the cabinet is the ambient temperature)	0°C - 50°C
	Whether the ambient humidity is within the specified range (when installed in the cabinet, the humidity in the cabinet is the ambient humidity)	10%-95% non-condensing
	Is there direct sunlight	No
	With or without droplets of water, oil, chemicals, etc.	No
	Whether there is dust, salt, iron filings, dirt	No
	Whether there is corrosive gas	No
	Whether there are flammable and explosive gases or articles	No
	Whether the device is subjected to	Should be within the range of

	vibration or shock	vibration resistance and impact resistance
	Is the heat dissipation good	Keep good ventilation and heat dissipation
Installation and Wiring Status	Whether the basic unit and the expansion unit are installed firmly	The mounting screws should be tightened without loosening
	Whether the connecting cables of the basic unit and the expansion unit are fully inserted	The connection cable cannot be loosened
	Are the screws of the external wiring loose	Screws should be tightened without loosening
	Whether the cable is damaged, aged, cracked	The cable must not have any abnormal appearance

## 4.2. Common Problems

Problems	Suggestions
It can't show HMI interface normally.	1. Resolution is set incorrectly, please set it according to hardware requirements.
The screen is not bright, the brightness is not enough.	1. Check HMI power, it should be powered enough.
It can't communicate	1. Check the network cable.
Click one, but wrong position	1. Please do HMI calibration again.
POWER led is ON, RUN led is OFF.	1. Check whether the power of the power supply is sufficient. At this time, it is best to supply power to the HMI alone, and restart it after adjustment. 2. Check whether the ALM light flickers regularly (hardware problem).
RUN led is ON, ALM led is ON.	1. Program running error, please check RTSys error code, and check application program.